


DietPi v7.4.2 version onwards boss2 OLED display can configure through
ssh login user name: root Password: dietpi.

dietpi-config -> Display Options -> LCD/OLED Panel addon



Dietpi OS image link:

http://3.230.113.73:9011/Allocom/Boss2/Dietpi/DietPi_RPi-ARMv7-Bullseye_AlloGUI.zip